






Quick Guide



- 1** Position the GMG carrier plate on a stable and level surface. Remove the two locking screws on the side of the carrier side of the carrier plate to be opened.




- 2** Unfold the GMG carrier plate. Ensure that it is aligned horizontally.




- 3** Loosen the 8 small fastening screws as well as the 2 large fastening screws on the start page.




Quick Guide




- 4** Place the sandpaper along the guide rails under the clamping rails. Fasten the clamping rails with the 10 fastening screws.



- 5** Position the GMG device on the start side of the carrier plate that the strap extraction points towards the target side. Pull out the strap extraction and hook the belt handle into the strap fixation. Start the measuring run.



- 6** The GMG device pulls itself independently over the sandpaper. The sandpaper can be used several times. Replace it as required. Remove the GMG device to stow the GMG backing plate. The sandpaper can remain on the backing plate.



- 7** When using a new sandpaper, a slit is created in the paper by the belt fixation. Secure the GMG carrier plate by tightening the two locking screws.